

Period: 2010-07-21 - 2010-07-27

Date	Process	PP Code	Product Type	Brand	Fit Model	Replace Code	Others
2010/7/21	Add	PL400B	Battery	SIGMA	SD15		Category: Digital Camera Related Products: AVCP400, ACMPB400, AVNS400, AVMP400
2010/7/21	Add	PL313B	Battery	SAMSUNG	ES50, PL55, SL502, SL720		Category: Digital Camera Related Products: AVEP313, AVCP313, ACMPB313, AVNS313, AVMP313
2010/7/21	Add	PL290B	Battery	SAMSUNG	NX		Category: Digital Camera Related Products: ACMPB290, AVCP290, AVNS290, AVMP290
2010/7/21	Add	PL372B	Battery	PENTAX	645		Category: Digital Camera Related Products: AVMP372, AVCP372, ACMPB372, AVNS372
2010/7/21	Add	PLW158B	Battery	PANASONIC	Lumix DMC-F2, Lumix DMC-FH20, Lumix DMC-FH22, Lumix DMC-FH3, Lumix DMC-FS11, Lumix DMC-FS30, Lumix DMC-FS33		Category: Digital Camera Related Products: AVEP158, AVCP158, ACMPB158, AVMP158, AVNS158
2010/7/21	Add	PL140B	Battery	FUJIFILM	FinePix JX530		Category: Digital Camera Related Products: AVCP140, AVEP140, AVMP140, AVNS140, ACMPB140
2010/7/21	Add	PL505C	Battery	SONY	HDR-FX1000, HDR-FX1000E		Category: Professional Camcorder Related Products: AVMP550, AVNS550, ACMPB503, AVCP503
2010/7/21	Add	PL505D	Battery	SONY	HDR-FX1000, HDR-FX1000E		Category: Professional Camcorder Related Products: AVMP550, AVNS550, ACMPB503, AVCP503
2010/7/21	Add	PLC506C	Battery	SONY	HDR-FX1000, HDR-FX1000E		Category: Professional Camcorder Related Products: AVMP550, AVNS550, ACMPB503, AVCP503
2010/7/21	Add	PLC506D	Battery	SONY	HDR-FX1000, HDR-FX1000E		Category: Professional Camcorder Related Products: AVMP550, AVNS550, ACMPB503, AVCP503
2010/7/21	Add	PLG506C	Battery	SONY	HDR-FX1000, HDR-FX1000E		Category: Professional Camcorder Related Products: AVMP550, AVNS550, ACMPB503, AVCP503
2010/7/21	Add	PLG506D	Battery	SONY	HDR-FX1000, HDR-FX1000E		Category: Professional Camcorder Related Products: AVMP550, AVNS550, ACMPB503, AVCP503
2010/7/21	Add	PL905C	Battery	SONY	HVR-Z5N, HVR-Z5P		Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550
2010/7/21	Add	PL905D	Battery	SONY	HVR-Z5N, HVR-Z5P		Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550

2010/7/21	Add	PLW905C	Battery	SONY	HVR-Z5N, HVR-Z5P	Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550
2010/7/21	Add	PLW905D	Battery	SONY	HVR-Z5N, HVR-Z5P	Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550
2010/7/21	Add	PLW906C	Battery	SONY	HVR-Z5N, HVR-Z5P	Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550
2010/7/21	Add	PLW906D	Battery	SONY	HVR-Z5N, HVR-Z5P	Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550
2010/7/21	Add	PLC906C	Battery	SONY	HVR-Z5N, HVR-Z5P	Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550
2010/7/21	Add	PLC906D	Battery	SONY	HVR-Z5N, HVR-Z5P	Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550
2010/7/21	Add	PL808D	Battery	JVC	GZ-HD310	Category: Camcorder Related Products: ACMPB808, AVNS808, AVMP808, AVCP808
2010/7/21	Add	PL818D	Battery	JVC	GZ-HD310	Category: Camcorder Related Products: ACMPB808, AVNS808, AVCP808, AVMP808
2010/7/21	Add	PL828D	Battery	JVC	GZ-HD310	Category: Camcorder Related Products: ACMPB808, AVNS808, AVCP808, AVMP808
2010/7/21	Add	PL705C	Battery	SONY	HVL-LBPA	Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550
2010/7/21	Add	PL705D	Battery	SONY	HVL-LBPA	Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550
2010/7/21	Add	PL905C	Battery	SONY	HVL-LBPA	Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550
2010/7/21	Add	PL905D	Battery	SONY	HVL-LBPA	Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550
2010/7/21	Add	PLC906C	Battery	SONY	HVL-LBPA	Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550
2010/7/21	Add	PLC906D	Battery	SONY	HVL-LBPA	Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550
2010/7/21	Add	PL705C	Battery	SONY	HDR-AX2000	Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550
2010/7/21	Add	PL705D	Battery	SONY	HDR-AX2000	Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550
2010/7/21	Add	PL905C	Battery	SONY	HDR-AX2000	Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550
2010/7/21	Add	PL905D	Battery	SONY	HDR-AX2000	Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550

2010/7/21	Add	PL341B	Battery	SAMSUNG	SMX-K40		Category: Camcorder Related Products: AVNS341, AVMP341, AVEP341, AVCP341, ACMPB341
2010/7/21	Add	PL341B	Battery	SAMSUNG	SMX-K45		Category: Camcorder Related Products: AVNS341, AVMP341, AVEP341, AVCP341, ACMPB341
2010/7/21	Add	PL600D	Battery	SONY	DCR-SR68/R, DCR-SR88, DCR-SX33E, DCR-SX63, DCR-SX83	NP-FV30	Category: Camcorder Related Products: AVMP55, AVNS55, AVCP55, ACMPB55
2010/7/21	Add	PL601D	Battery	SONY	DCR-SR68/R, DCR-SR88, DCR-SX33E, DCR-SX63, DCR-SX83	NP-FV30	Category: Camcorder Related Products: AVMP55, ACMPB55, AVCP55, AVNS55
2010/7/21	Add	PL602D	Battery	SONY	DCR-SR68/R, DCR-SR88, DCR-SX33E, DCR-SX63, DCR-SX83	NP-FV30	Category: Camcorder Related Products: AVMP55, ACMPB55, AVCP55, AVNS55
2010/7/21	Delete	PL65D	Battery	SONY	DCR-SX83		Category: Camcorder Related Products: ACMPB55, AVMP55, AVNS55, AVCP55
2010/7/21	Delete	PL66D	Battery	SONY	DCR-SX83		Category: Camcorder Related Products: AVMP55, AVNS55, AVCP55, ACMPB55
2010/7/21	Delete	PL67D	Battery	SONY	DCR-SX83		Category: Camcorder Related Products: AVMP55, AVNS55, AVCP55, ACMPB55
2010/7/21	Delete	PL68D	Battery	SONY	DCR-SX83		Category: Camcorder Related Products: AVMP55, AVNS55, AVCP55, ACMPB55
2010/7/21	Delete	PL69D	Battery	SONY	DCR-SX83		Category: Camcorder Related Products: AVMP55, AVNS55, AVCP55, ACMPB55
2010/7/21	Add	PLW154B	Battery	LEICA		BP-DC7BP-DC	Category: Digital Camera Related Products: AVEP154, AVMP154, AVCP154, ACMPB154, AVNS154

2010/7/21	Add	PLW154B	Battery	PANASONIC	Lumix DMC-TZ10, Lumix DMC-TZ6, Lumix DMC-TZ7, Lumix DMC-TZ8, Lumix DMC-ZR1, Lumix DMC-ZR1A, Lumix DMC-ZR1K, Lumix DMC-ZR1R, Lumix DMC-ZR1S, Lumix DMC-ZR1W, Lumix DMC-ZS1, Lumix DMC-ZS1K, Lumix DMC-ZS1S, Lumix DMC-ZS3, Lumix DMC-ZS3A, Lumix DMC-ZS3K, Lumix DMC-ZS3S, Lumix DMC-ZS5, Lumix DMC-ZS7, Lumix DMC-ZX1, Lumix DMC-ZX1A, Lumix DMC-ZX1K, Lumix DMC-ZX1R, Lumix DMC-ZX1S, Lumix DMC-ZX1W, Lumix DMC-ZX3, Lumix DMC-ZX3N, Lumix DMC-ZX3R, Lumix DMC-ZX3S, Lumix DMC-ZX3T		Category: Digital Camera Related Products: AVEP154, AVMP154, AVCP154, ACMPB154, AVNS154
2010/7/21	Add	PLW154B	Battery	LEICA	V-Lux 20		Category: Digital Camera Related Products: AVEP154, AVMP154, AVCP154, ACMPB154, AVNS154
2010/7/21	Add	PLW154B	Battery	LEICA		BP-DC7E, BP-DCU	Category: Digital Camera Related Products: AVEP154, AVMP154, AVCP154, ACMPB154, AVNS154
2010/7/22	Delete	TL1834B	Battery	HITACHI	C 18DL, C 18DLX, C 18DMR, C 6DC, C 6DD		Category: Power Tools
2010/7/22	Amend	RB109G.11N	Battery				Color: Grey -> Black
2010/7/22	Amend	RB109G.12N	Battery				Color: Grey -> Black
2010/7/22	Amend	RB109G.15N	Battery				Color: Grey -> Black
2010/7/22	Amend	RB109G.20H	Battery				Color: Grey -> Black
2010/7/22	Amend	RB109G.21H	Battery				Color: Grey -> Black
2010/7/22	Amend	RB109G.27H	Battery				Color: Grey -> Black
2010/7/23	Add	PL158B	Battery	PANASONIC	Lumix DMC-F2, Lumix DMC-FH20, Lumix DMC-FH22, Lumix DMC-FH3, Lumix DMC-		Category: Digital Camera Related Products: AVEP158, AVCP158, ACMPB158, AVMP158, AVNS158
2010/7/23	Add	PD648B	Battery	DELL		U6191	Category: PDA Related Products: AVMP647, AVNS647, ACMPB648, AVCP648, AVEP648

2010/7/23	Add	BL8800B	Battery	PANASONIC	EB-X800		Category: Mobile Phone
2010/7/23	Delete	BL8800B	Battery	PANASONIC	X800		Category: Mobile Phone
2010/7/23	Add	BL3872A	Battery	MOTOROLA		SNN5753A	Category: Mobile Phone
2010/7/23	Add	PD417B	Battery	HP		364401-002	Category: PDA Related Products: AVEP417, AVCP417, ACMPB417
2010/7/23	Add	PL818D	Battery	JVC	GZ-HD30AC, GZ-HD40AC		Category: Camcorder Related Products: ACMPB808, AVNS808, AVCP808, AVMP808
2010/7/23	Add	PL828D	Battery	JVC	GY-HM100, GY-HM100U, GZ-HD30AC, GZ-HD40AC		Category: Camcorder Related Products: ACMPB808, AVNS808, AVCP808, AVMP808
2010/7/23	Add	PLC706C	Battery	SONY	HDR-FX1000, HDR-FX1000E		Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550
2010/7/23	Add	PLC706D	Battery	SONY	HDR-FX1000, HDR-FX1000E		Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550
2010/7/23	Add	PLC906C	Battery	SONY	HDR-FX1000, HDR-FX1000E		Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550
2010/7/23	Add	PLC906D	Battery	SONY	HDR-FX1000, HDR-FX1000E		Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550
2010/7/23	Add	PLW905C	Battery	SONY	HDR-FX1000, HDR-FX1000E		Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550
2010/7/23	Add	PLW905D	Battery	SONY	HDR-FX1000, HDR-FX1000E		Category: Professional Camcorder Related Products: AVCP503, AVNS550, AVMP550
2010/7/23	Add	PLG505C	Battery	SONY	HDR-FX1000, HDR-FX1000E		Category: Professional Camcorder Related Products: AVMP550, AVNS550, ACMPB503, AVCP503
2010/7/23	Add	PLG505D	Battery	SONY	HDR-FX1000, HDR-FX1000E		Category: Professional Camcorder Related Products: AVMP550, AVNS550, ACMPB503, AVCP503
2010/7/23	Add	PL140B	Battery	FUJIFILM	FinePix JX280, FinePix Z80, FinePix Z800EXR, FinePix Z808EXR, FinePix Z81		Category: Digital Camera Related Products: AVCP140, AVEP140, AVMP140, AVNS140, ACMPB140
2010/7/23	Add	PL140B	Battery	OLYMPUS	X-905		Category: Digital Camera Related Products: AVCP140, AVEP140, AVMP140, AVNS140, ACMPB140
2010/7/23	Add	PLW154B	Battery	PANASONIC	Lumix DMC-TZ10K, Lumix DMC-TZ10N, Lumix DMC-TZ10R, Lumix DMC-TZ10S		Category: Digital Camera Related Products: AVEP154, AVMP154, AVCP154, ACMPB154, AVNS154
2010/7/23	Add	PL182G	Battery	SONY	Cyber-shot DSC-H55, Cyber-shot DSC-HX5B, Cyber-shot DSC-HX5V		Category: Digital Camera Related Products: AVEP181, AVCP181, ACMPB181, AVMP181, AVNS181

2010/7/23	Delete	PL182G	Battery	SONY	DSC-HX5B, DSC-HX5V		Category: Digital Camera Related Products: AVEP181, AVCP181, ACMPB181, AVMP181, AVNS181
2010/7/23	Add	PL178B	Battery	SANYO	Xacti VPC-X1220, Xacti VPC-X1420, Xacti VPC-X1200		Category: Digital Camera Related Products: AVEP178, AVMP178, AVCP178, ACMPB178, AVNS178
2010/7/23	Add	PL340B	Battery	SAMSUNG	HZ30W, HZ35W, WB600, WB650		Category: Digital Camera Related Products: ACMPB340, AVCP340, AVEP340, AVMP340, AVNS340
2010/7/23	Add	PL140B	Battery	CASIO	Exilim EX-Z350		Category: Digital Camera Related Products: AVCP140, AVEP140, AVMP140, AVNS140, ACMPB140
2010/7/23	Add	PL368B	Battery	FUJIFILM	FinePix F300EXR, FinePix F305EXR		Category: Digital Camera Related Products: AVCP368, AVEP368, AVMP368, AVNS368, ACMPB368
2010/7/23	Add	PL153B	Battery	SONY	Cyber-shot DSC-W180/S, Cyber-shot DSC-W190/R		Category: Digital Camera Related Products: AVNS152, AVEP152, AVCP152, ACMPB152, AVMP152
2010/7/26	New Product	CL1032A.082	Battery	ASUS			
2010/7/26	Revised	CL1032A.086	Battery	ASUS			
2010/7/26	Revised	CL1032A.087	Battery	ASUS			
2010/7/26	Revised	CL1032A.080	Battery	ASUS			
2010/7/26	Revised	CL1032A.083	Battery	ASUS			
2010/7/26	Revised	CL1032A.085	Battery	ASUS			
2010/7/26	Revised	CL3646M.080	Battery	DELL			
2010/7/26	Revised	CL3646M.082	Battery	DELL			
2010/7/26	Revised	CL3646M.083	Battery	DELL			
2010/7/26	Revised	CL3646M.085	Battery	DELL			
2010/7/26	Revised	CL3646M.086	Battery	DELL			
2010/7/26	Revised	CL3646M.087	Battery	DELL			
2010/7/26	Revised	CL5123B.080	Battery	SONY			
2010/7/26	Revised	CL5123B.086	Battery	SONY			
2010/7/26	Revised	CL5123B.083	Battery	SONY			
2010/7/26	Revised	CL5123B.082	Battery	SONY			
2010/7/26	Revised	CL5123B.085	Battery	SONY			
2010/7/26	Revised	CL5123B.087	Battery	SONY			
2010/7/26	Revised	CL3430M.080	Battery	DELL			
2010/7/26	Revised	CL3430M.082	Battery	DELL			
2010/7/26	Revised	CL3430M.083	Battery	DELL			
2010/7/26	Revised	CL3430M.085	Battery	DELL			
2010/7/26	Revised	CL3430M.086	Battery	DELL			
2010/7/26	Revised	CL3430M.087	Battery	DELL			

2010/7/26	Add	CL5811A	Battery	APPLE	MacBook 13" MC374LL/A, MacBook 13" MC375LL/A, MacBook 13" MB881LL/A		Category: Laptop
2010/7/26	Add	CL5811A	Battery	APPLE		MA561LL/A	Category: Laptop
2010/7/26	Add	C2	Connector Tips	SAMSUNG	N310, NB30, NP--NB30- JA02HK, NP-N110-KA01DE, NP-N120-KA01DE, NP-N120- KA02DE, NP-N120-KA05DE, NP-N120-KA06DE, NP-N130- ET01DE, NP-N130-JA01DE, NP-N130-JA02DE, NP-N130- KA01DE, NP-N130-KA02DE, NP-N130-KA03DE, NP-N130- KA04DE, NP-N140-KA01DE, NP-N140-KA03DE, NP-N150- HAZ1DE, NP-N150-JA02DE, NP-N150-JA03DE, NP-N220- JA02DE, NP-N220-JA03DE, NP-N220-JA04DE, NP-N310, NP-N310-KA01DE, NP-N510- HAZ1DE, NP-N510-JA03DE, NP-N510-JA05DE, NP-N510- JB01DE, NP-N510-JB02DE, NP-N510-KA02DE, NP-N510- KA03DE, NP-NB30-JA01DE, NP-NB30-JT01DE, NP-NC10- KA01DE, NP-NC10-KA03DE, NP-NC10-KA05DE, NP-NC10- KA06DE, NP-NC10-KAY1DE, NP-NC10-KAY2DE, NP-NC20- KA02DE, NP-X420-AA01DE, NP-X420-FA02DE, NP-X420- JA02DE, NP-X420-JA03D, NP- X520-AA01DE, NP-X520- FA03DE, NP-X520-JB02DE		Category: Laptop Related Products: AC090.008C2, DC091.006C2, DC090.006C2, AC090X.008, EL1901, EL1691, EL1692, EL1695, EL1696
2010/7/26	Add	C26	Connector Tips	ASUS	Eee PC 1008P		Category: Laptop AC & DC Adapter Related Products: AC090.008C26, DC091.006C26, AC090X.008
2010/7/26	Add	PLW139B	Battery	PANASONIC	Lumix DMC-G10, Lumix DMC- G10K		Category: Digital Camera Related Products: AVMP139, AVEP139, AVCP139, ACMPB139, AVNS139

2010/7/27	Add	C2	Connector Tips	SAMSUNG	<p>N110-anyNet N270 BBT, N120-anyNet N270 BBT, N120-anyNet N270 BN59, N120-anyNet N270 WBT, N120-anyNet N270 WN59, N130-anyNet N270 B3N, N130-anyNet N270 BN7, N130-anyNet N270 WN, N130-anyNet N270 WN7, N130-anyNet N270BN, N130-anyNet N280BN, N140-anyNet N270 BNBT21, N140-anyNet N270 WNBT21, N150-Elijah, N150-Elijah, N150-Eom 3G, N220-Maroh, N220-Marvel, N220-Mito, N310-anyNet N270 BBT, N310-anyNet N270 MBT, N510-anyNet N270 WBT21, N510-BN7BT, N510-Mika, N510-Mika 3G, N510-Mila, N510-Mino, NB30, NB30-Pro Palm, NB30-Pro Palm Touch, NC10-anyNet N270 A, NC10-anyNet N270 B, NC10-anyNet N270 BBT, NC10-anyNet N270 BH, NC10-anyNet N270 WBT, NC10-anyNet N270 WH, NC10-anyNet N270W, NC20-anyNet U2250 WBT, X120-Aura SU7300 Akio, X120-Aura SU7300 Avion, X420-Aura SU2700 Aven, X420-Aura SU3500 Anno, X420-Aura SU4100 Kami, X420-Aura SU4100 Logan, X520-Aura SU2700 Addi, X520-Aura SU3500 Alon, X520-Aura SU4100 Akiva</p>		<p>Category: Laptop</p> <p>Related Products: AC090.008C2, DC091.006C2, DC090.006C2, AC090X.008, EL1901, EL1691, EL1692, EL1695, EL1696</p>
2010/7/28	Add	C7	Connector Tips	ACER	<p>Aspire 5536, Aspire 5536G, Aspire 5935, Aspire 5949, Aspire 7540G, Aspire 8540G, Aspire 8735G, Aspire 8735ZG, Aspire TimelineX 4820TG</p>		<p>Category: Laptop</p> <p>Related Products: AC090.008C7, DC091.006C7, DC090.006C7, AC090X.008, EL1901, EL1692</p>

2010/7/29	Add	PL106B	Battery	OLYMPUS	E-600	Category: Digital Camera Related Products: AVCP106, AVMP106, AVNS106, ACMPB106
2010/7/29	Amend	CL5123B	Battery			Remark: -> You will be required to install a non-hazardous program to ensure the battery be 100% compatible with your laptop. This program will update the underlying device driver of intelligent lithium battery, including the BIOS. Please read the instruction manual carefully before you start to install the program.
2010/7/30	Add	C2	Connector Tips	SAMSUNG	N110-12PBK, N120-12GBK, N120-12GW, N130-13B, N130-13P, N140-14B, N140-14R, N310, N310-13GB, N310-13GO, NC10-11GP, NC10-12PWBK, NC10-13GB, NC10-13P, NC10-14GB, NC10-14GBK, NC10-14GW, NC20-21GBK, P460-42P, P560-52P, P560-54G, P560-54P, Q320-32P, R522-52S, R610-62G, R610-64G, R620-63G, X460-41P, X460-41S, X460-42PW	Category: Laptop Related Products: AC090.008C2, DC091.006C2, DC090.006C2, AC090X.008, EL1901, EL1691, EL1692, EL1695, EL1696