

Date	Process	PP Code	Product Type	Brand	Fit Model	Replace Code	Others
2010-5-28	Add	Z6	Power Cable	ACCEL	AccelNote CY13		Category: Laptop Related Products: EL1901, EL1692
2010-5-28	Add	Z6	Power Cable	HP COMPAQ	Business Notebook n1050v, Business Notebook nx9000, Business Notebook nx9005, Business Notebook NX9008, Business Notebook nx9010		Category: Laptop Related Products: EL1901, EL1692
2010-5-28	Delete	Z6	Power Cable	HP COMPAQ	AccelNote CY13, Business Notebook n1050v, Business Notebook nx9000, Business Notebook nx9005, Business Notebook NX9008, Business Notebook nx9010		Category: Laptop
2010-5-31	New Product	CL1397B.080	Battery	ACER			
2010-5-31	New Product	CL1397B.082	Battery	ACER			
2010-5-31	New Product	CL1397B.083	Battery	ACER			
2010-5-31	New Product	CL1397B.085	Battery	ACER			
2010-5-31	New Product	CL1397B.086	Battery	ACER			
2010-5-31	New Product	CL1397B.087	Battery	ACER			
2010-5-31	New Product	CL2492B.080	Battery	HP			
2010-5-31	New Product	CL2492B.082	Battery	HP			
2010-5-31	New Product	CL2492B.083	Battery	HP			
2010-5-31	New Product	CL2492B.085	Battery	HP			
2010-5-31	New Product	CL2492B.086	Battery	HP			
2010-5-31	New Product	CL2492B.087	Battery	HP			
2010-5-31	New Product	CL5115S.080	Battery	SONY			
2010-5-31	New Product	CL5115S.082	Battery	SONY			
2010-5-31	New Product	CL5115S.083	Battery	SONY			
2010-5-31	New Product	CL5115S.085	Battery	SONY			
2010-5-31	New Product	CL5115S.086	Battery	SONY			

Date	Process	PP Code	Product Type	Brand	Fit Model	Replace Code	Others
2010-5-31	New Product	CL5115S.087	Battery	SONY			
2010-5-31	New Product	CL6312B.080	Battery	FUJITSU			
2010-5-31	New Product	CL6312B.082	Battery	FUJITSU			
2010-5-31	New Product	CL6312B.083	Battery	FUJITSU			
2010-5-31	New Product	CL6312B.085	Battery	FUJITSU			
2010-5-31	New Product	CL6312B.086	Battery	FUJITSU			
2010-5-31	New Product	CL6312B.087	Battery	FUJITSU			
2010-5-31	New Product	PL289B.354	Battery	SAMSUNG			
2010-5-31	New Product	PLW133B.443	Battery	OLYMPUS			
2010-5-31	Add	CL4566B	Battery	TOSHIBA	Satellite U505-S2012		Category: Laptop
2010-5-31	Add	CL4363B	Battery	TOSHIBA	Satellite U505-S2012		Category: Laptop
2010-5-31	Add	CL1026B	Battery	SAMSUNG	P460-42P, P560-52P, P560-54G, P560-54P, R610-64G, X460-41P, X460-41S		Category: Laptop
2010-6-1	Add	PL940B	Battery	SIGMA	DP1x, DP2s		Category: Digital Camera Related Products: AVMP940, AVNS940
2010-6-1	Add	PL140B	Battery	SANYO	Xacti VPC-T1060, Xacti VPC-T700, Xacti VPC-T700T, Xacti VPC-T850	LI-42B	Category: Digital Camera Related Products: AVCP140, AVEP140, AVMP140, AVNS140, ACMPB140
2010-6-1	Add	TL1305G	Battery	RYOBI	CAH120LK, CD100, HJP002, HP612K, JG001		Category: Power Tools
2010-6-1	Delete	TB1817B	Battery	RYOBI	CID-182L, P200, P210, P2100, P211, P220, P230, P240, P2400, P2500, P2600, P300, P301, P310, P3200, P3300, P400, P410, P420, P430, P500, P501, P510, P520, P521, P530, P540, P600, P610, P700, P710, P730, P740	130224028, 130255004, ABP1804, BPL1820, P100	Category: Power Tools

Date	Process	PP Code	Product Type	Brand	Fit Model	Replace Code	Others
2010-6-1	Delete	TL1817B	Battery	RYOBI	CID-182L, P200, P210, P2100, P211, P220, P230, P240, P2400, P2500, P2600, P300, P301, P310, P3200, P3300, P400, P410, P420, P430, P500, P501, P510, P520, P521, P530, P540, P600, P610, P700, P710, P730, P740	130224028, 130255004, ABP1804, BPL1820, P100	Category: Power Tools
2010-6-1	Delete Product	CL1026B.07P	Battery				
2010-6-1	Delete Product	CL1026B.085	Battery				
2010-6-2	Add	PLW133B	Battery	OLYMPUS	FE-4040, X-940		Category: Digital Camera Related Products: AVNS133, ACMPB133, AVCP133, AVEP133, AVMP133
2010-6-2	Delete	TB1441B	Battery	HITACHI	DH 20DV		Category: Power Tools
2010-6-2	Delete	TB1441G	Battery	HITACHI	DH 20DV		Category: Power Tools
2010-6-2	Delete	TL1415B	Battery	HITACHI	DH 20DV		Category: Power Tools
2010-6-2	Delete	TL1416B	Battery	HITACHI	DH 20DV		Category: Power Tools
2010-6-2	Add	TB140R	Battery	BOSCH	PSR14.4VES-2	2 607 335 160, 2 607 335 246	Category: Power Tools
2010-6-2	Add	PL140B	Battery	OLYMPUS	X-915, X-920, X-935, X-960		Category: Digital Camera Related Products: AVCP140, AVEP140, AVMP140, AVNS140, ACMPB140
2010-6-2	Add	PL249L	Battery	OLYMPUS	X-36 / T-100		Category: Digital Camera Related Products: AVMP249, AVNS249
2010-6-2	Amend	CL2491B.087	Battery				Voltage: 11.10 V -> 14.40 V
2010-6-3	Add	PL182G	Battery	SONY	DSC-HX5B, DSC-HX5V		Category: Digital Camera Related Products: AVEP181, AVCP181, ACMPB181, AVMP181, AVNS181
2010-6-3	Add	CL1576B	Battery	ACER	Aspire 8940G		Category: Laptop
2010-6-3	Add	CL2210B	Battery	HP		HSTNN-DB04, HSTNN-DB14	Category: Laptop
2010-6-3	Add	CL2211B	Battery	HP		HSTNN-DB04, HSTNN-DB14, HSTNN-IB14	Category: Laptop